


Backup Utility User Manual V1.0


1. Backup task list window



Dia. 1

2. OPEN: Open task files.
3. SAVE : save your task to “*.iniBackup” file
4. Disk Properties: display the disk information
5. ADD : add a new task, the “Edit Task” menu will display as Dia. 2
6. NEW : create a job list
7. DELETE : delete the task that you selected.
8. Modify : modify the task properties.
9. EXECUTE : execute the task list
10. EXIT: exit the program
11. enable the block to load the task file automatically.

2.Task setting manu



Dia. 2

Path setting:

- 1. Source Directory** Browse the directory for backup source setting.
- 2. Destination Directory** Browse the directory for backup target setting(external enclosure).

Backup attribute setting:


- 3. Active** enable for backup button function
- 4. All Files + Subdirectory** enable to backup all files & subdirectory.
- 5. All Files** enable to backup all files, the subdirectory excluded.
- 6. Newer** enable to backup only newer files
- 7. Archive** enable to backup only archive files

Action option


- 8. Backup** **Backup the task list to target directory.**
- 9. Restore** **Restore the backup file to replace the source directory.**
- 10. Copy** **Copy the task list files to target directory.**

Add the task.


Step 1: click the “add” button.




Step 2: Press “Browse” to modify the source & destination directory.




Step 3: After the path & function setting, press “OK”.



Step 4: Return to main menu, press “save” to save the task file.



Step 5: return to main menu.



Step 6: PUSH BUTTON · to start the backup function

